

ZH / 用户手册 / 组装说明 EN / Instructions for use / Assembly instructions AXOR One 75 ljet 48490XX7

02

02

△ 安全技巧

- △ 装配时为避免挤压和切割受伤,必须戴上手套,
- △ 必须避免让身体敏感部位 (如眼睛) 接触到莲蓬头 喷水, 必须保持莲蓬头与人头之间有足够的距离,
- △ 本产品只允许作为洗浴, 卫生和洁身之用。
- ▲ 头顶花洒夹持杆只为夹持头顶花洒而设计, 不得让 **其承载其它物品**

安装提示

/ 必须装上花洒所附带的滤柱式过滤网 以过滤管道 里的杂质污物,杂质污物会影响花洒的功能和/或损 坏花洒的功能部件, 由此而产生的产品损坏不属于 汉斯格雅的保修范围

技术参数

工作压强: 最大 0.6 MPa 推荐工作压强: 0.1 - 0.4 MPa 测试压强: 1.6 MPa

(1 MPa = 10 bar = 147 PSI)

最大 60°C

热水温度: 该产品专为饮用水设计!

符号说明



请勿使用含有乙酸的硅胶!



流量示意图 (参见第页 03)



备用零件(参见第页04)



清洗 (参见第页 O5)

淋浴器水效等级

本公司淋浴器产品水效等级符合GB 28378-2019《淋 浴器水效限定值及水效等级》的要求淋浴器水效等级 指标如下表:

流量

类型	1级	2级	3 级
手持式花洒	≤ 4.5	≤ 6.0	≤ 7.5
固定式花洒	≤ 4.5	≤ 6.0	≤ 9.0
			(单位升每分

(注:您所购买的产品的水效等级以产品或包装物上标 识的水效等级为准.)

A SAFFTY NOTES

- ▲ Gloves should be worn during installation to prevent crushing and cutting injuries.
- ⚠ Do not allow the streams of the shower touch sensitive body parts (such as your eyes). An adequate distance must be kept between the shower and you.
- ⚠ The product may only be used for bathing, hygienic and body cleaning purposes.
- Δ The arm of the shower head is intended only to hold the shower head. Do not load it down with other objects!

INSTALLATION INSTRUCTIONS

/ The filter insert must be used to protect the shower against incoming dirt by pipework. Incoming dirt leads to defects or/and can damage parts of the shower; such caused faults voids all liability and quarantee claims.

TECHNICAL DATA

Operating pressure: max. 0,6 MPa 0,1 - 0,4 MPa Recommended operating pressure:

Test pressure: 1.6 MPa (1 MPa = 10 bar = 147 PSI)

Hot water temperature: max. 60°C The product is exclusively designed for drinking water!

SYMBOL DESCRIPTION



Do not use silicone containing acetic acid!

DIMENSIONS (see page 03)

FLOW DIAGRAM (see page 03)

SPARE PARTS (see page 04)

CLEANING (see page 05)

WATER EFFICIENCY GRADES FOR SHOWFRS

The water efficiency grades of Hansgrohe's showers meet the requirements of GB 28378-2019 "Minimum allowable values of water efficiency and water efficency grades for showers". The indexes of water efficency grades for showers are as follows:

FLOW RATE


	TYPE	GRADE 1	GRADE 2	GRADE 3
	Hand-held shower	≤ 4.5	≤ 6.0	≤ 7.5
	Fixed shower head	≤ 4.5	≤ 6.0	≤ 9.0

(In L/min)


(Note: For the actual water efficiency grade of the purchased product, please refer to the water efficiency grade indicated on the product or package.)


















- XX = 颜色代码/Colors
- 00 = Chrome Plated
- 14 = Brushed Bronze
- 25 = Brushed Gold-Optic
- 30 = Polished Redgold
- 31 = Brushed Redgold
- 33 = Polished Black Chrome
- 34 = Brushed Black
- 67 = Matt Black
- 80 = Stainless Steel Optic
- 82 = Brushed Nickel
- 95 = Brushed Brass
- 99 = Polished Gold-Optic































汉斯格雅产品的清洁建议

现代的卫浴龙头, 厨房龙头, 花洒, 配件, 盥洗台, 洗涤盆, 浴盆和加热器采用的制造材料非常迥异, 以适应产品外形设计和使用功能的市场需求.

为了避免产品损坏和由此引发的投诉及争议,必须在使用和清洁产品时遵循有关规程.

在保养汉斯格雅产品时,原则上必须注意:

- / 只能使用那些有明确注明是适用于本产品的清洁剂.
- / 不允许使用含有盐酸, 蚁酸, 浓氢氧化钠, 氯漂或醋酸的清洁剂, 因为这些清洁剂会给产品表面造成严重的损伤
- / 含磷酸的清洁剂必须在特定条件下使用.
- / 不允许将两种以上清洁剂混合使用.
- / 不允许使用具有研磨作用的清洁工具和设备,如不适合的清洁粉末,海绵垫或超细麦克布.
- / 务必遵守清洁剂制造商的安全说明
- / 严格遵守清洁剂的用量和作用时间, 决不允许清洁 剂的作用时间长于规定值.
- / 定期的清洁以预防水垢.
- / 不允许将清洁剂直接喷射到汉斯格雅产品上,因为喷雾会进入汉斯格雅产品的开口部分和缝隙中而造成损害。首先将清洁剂喷在软布上,再用软布进行清洁。
- / 清洁之后必须用足够的清水冲洗, 以彻底去除残留的吸附物 (清洁剂).
- / 不允许使用蒸汽清洗机,高温会损害产品.

重要说明

肥皂, 洗发水, 沐浴液, 染发剂, 香水, 刮胡水, 指甲油的 残留也会对产品造成损伤.

此处: 使用后要小心地用清水将剩余物冲洗干净.

同样在产品下方不得存放洗涤剂和化学药品,例如不可放在用于洗脸盆的梳洗柜中否则挥发气体将损坏产品.在已经损伤的表面继续使用清洁剂会给表面造成更大的损伤.



表面损坏的部件必须更换, 否则会有受伤的危险.


不按规定进行清洁而造成的任何损坏不在本公司产品 保修范围之内


担保

Axor向用户保证,该产品无制造缺陷.如果在担保期内出现缺陷,Axor将免费进行售后处理,保证条件和详情见www.hansgrohe.com.cn/service/producer-quarantee.在提出保修的权利时请联系您的合同方.本保证不涉及有关国家法律规定的消费权益

QuickClean

有了QuickClean, 手工清洁功能, 要去掉喷头上的水垢, 只需简单地搓除即可.







CLEANING RECOMMENDATION FOR AXOR PRODUCTS

Today, modern sanitary and kitchen tapware, showers, accessories, washstands, sinks, tubs and radiators consist of very different materials to comply with the needs of the market with regard to design and functionality.

To avoid damage and reclamations, it is necessary to consider certain criteria when cleaning.

WITH REGARD TO CARING FOR THE AXOR PRODUCTS, THE FOLLOWING MUST IN PRINCIPLE BE HEEDED:

- / Only use cleaning material which is explicitly provided for this type of application.
- / Never use cleaning materials, which contain hydrochloric acid, formic acid, concentrated caustic soda, chlorine pale lye or acetic acid, as they cause considerable damage.
- Phosphorus acidic cleaners are only conditionally applicable.
- / Mixing cleaning agents is not permitted, generally.
- / Never use cleaning materials or appliances with an abrasive effect, such as unsuitable cleaning powders, sponge pads or micro fibre cloths.
- / The safety instructions of the cleaning agent manufacturers must be strictly followed.
- / Cleaning has to be carried out with a specified cleaner dosage, contact time, object-related and adapted to the needs.
- / The building up of calcifications has to be removed by cleaning regulary.
- / When using spray cleaners, spray the cleaning solution onto a soft cloth or sponge, never directly onto the Axor products, as the atomised spray could enter openings and gaps in the Axor products and cause damage.

- / After cleaning rinse thoroughly with clean water to remove any cleaner residue.
- / The use of steam cleaners is not permitted. The high temperatures can damage the products.

IMPORTANT

Residues of toiletries such as liquid soaps, shampoos and shower gels, hair dyes, perfumes, aftershave and nail varnish can also cause damage.

Here too: Carefully rinse with water after use to remove residues.

Likewise, do not store any cleaning agents or chemicals under the products, for example in a vanity unit, as the vapours may damage the products.

The damage of already damaged surfaces will deteriorate under the effect of the cleansers



COMPONENTS WITH
DAMAGED SURFACES MUST BE
EXCHANGED, OTHERWISE THERE
COULD BE AN INJURY DANGER.

Damage caused by improper treatment will not be covered by our guarantee.


WARRANTY

Axor guarantees to the consumer that this product is free of production faults. If any defect is detected within the warranty period, Axor will remedy this defect free of charge. You will find the conditions and details of this guarantee at www.hansgrohe.com.cn/service/producer-quarantee. Please contact your contracting party to claim your rights under this guarantee. This guarantee does not affect the customer's rights under the respective national legislation.


QUICKCLEAN

The QuickClean cleaning function only needs a small manual rub over to remove the lime scale from the spray channels.





AXOR



- ZH / 注意! 表面损坏的部件必须更换, 否则会有 受伤的危险.
- EN / Important! Components with damaged surfaces must be exchanged, otherwise there could be an injury danger.

AXOR / Hansgrohe SE Auestraße 5-9 77761 Schiltach Deutschland